


3-¹⁵/₃₂" Wide

Mounting Diagram - Happ 49-Way Joystick

Proper Orientation
for use with the
Groovy Game Gear
GP-WIZ 49

3-³/₃₂" Tall



Floppy Cable Connector