



This wiring method disables the "on-the-fly" codeset switching feature.

NOTE: If wired in this manner only the KeyWiz Uploader software can switch between codesets.



KeyWiz™ Wiring Examples

(Advanced)

● = Connection Point

Copyright 2003 - IDVT Inc.
All Rights Reserved
www.groovygamegear.com