low cost 16-port keyboard I/O encoder/expander

—————Wiring Guide for 1P 2P alternating classic————

ESC

TOKN KB16
mounting
area

1P   2P

JOY
STICK

JUMP   FIRE

COIN

*

PC FLOPPY or IDE flat cable

● = CONNECTION POINT

NC
NO
COM

This is preliminary information and is subject to change without notice. * The last two floppy wires opposite the pin 1 red wire are unused.

low cost 16-port keyboard I/O encoder/expander

─────── Wiring Guide for 1P 2P simultaneous classic ───────

TOKN KB16
mounting
area

ESC

1P   2P

JOY STICK   JUMP   FIRE   JOY STICK   JUMP   FIRE

COIN

*

PC FLOPPY or IDE flat cable

● = CONNECTION POINT

NC
NO
COM

This is preliminary information and is subject to change without notice. * The last two floppy wires opposite the pin 1 red wire are unused.

low cost 16-port keyboard I/O encoder/expander

—————Wiring Guide for SoloMax desktop console—————

ESC

PAUSE

TOKN KB16
mounting
area

1P

2P

ROTATE
LEFT

ROTATE
RIGHT

JOY
STICK

THRUST

FIRE

SHIELD

HYPER

SMART
BOMB

1N4001

1N4001

COIN

*

PC FLOPPY or IDE flat cable

● = CONNECTION POINT

NC
NO
COM

This is preliminary information and is subject to change without notice. * The last two floppy wires opposite the pin 1 red wire are unused.

low cost 16-port keyboard I/O encoder/expander

————Wiring Guide Advanced, SoloMax Staggered & Bussed————

ESC

PAUSE

TOKN KB16
mounting
area

1P

2P

ROTATE
LEFT

ROTATE
RIGHT

JOY
STICK

THRUST

FIRE

SHIELD

HYPER

SMART
BOMB

1N4001

1N4001

COIN

GND2

GND1

*

PC FLOPPY or IDE flat cable

● = CONNECTION POINT

NC
NO
COM

This is preliminary information and is subject to change without notice. * The last two floppy wires opposite the pin 1 red wire are unused.